

Small Block Chevy Throttle/Kick down Bracket

1. Remove the back 2(two) intake manifold bolts on the drivers side of your motor.
2. Install main bracket using 3/8 -16x 1 ¼ hex head bolt(provided)
3. Tighten these bolts completely.
4. Align the bracket, using the palm of your hand. A simple push will bend the mounting tabs for a perfect fit
5. Install your cables, we have cut these bracket to fit stock GM Style cables. However, a couple of washers will allow you to mount any cable desired.
6. Adjust the independent cable holders as desired, lock the nuts down with some thread lock, and you are ready to go.

Note: If you have a powder coated bracket, you may have to use a razor to skim out the powder coat in the cable mount for a perfect fit.



Part numbers

7701-r, 7701P,
7701pnh

7701-Phantom

CNC CUSTOMS AND MANUFACTURING, INC. ~~ A DIVISION OF CNC CONGLOMERATE

SANTA ANA, CA. 714) 289-9060- PHONE

714) 289-9627-FAX